MANUAL GIGABLUE

DIGITAL MULTIMEDIA RECEIVER





www.gigablue.de

MANUAL GIGABLUE BOX

Initiation

Dear Customer,

Thank you for choosing to buy a GigaBlue UHD Trio 4K.

This manual is intended to help you connect your GigaBlue Box correctly and to get to know the numerous functions better.

The GigaBlue UHD Trio 4K is a world first with a fast Hi3798MV200 Quad Core 1.6 GHz processor, 1 GB RAM and 8GB Flash, the possibilities of this multimedia box are very extensive. With the fast Gigabit LAN you achieve the highest performance in your private and external network. A media portal is also integrated in the software.

You can use the GigaBlue Box as a web browser, picture archive, music archive, film archive and many other functions.

You can adapt the GigaBlue Box to your requirements using the plug-in service.

We hope you enjoy reading the manual and of course using your GigaBlue UHD Trio 4K.

Should a problem arise with your GigaBlue UHD 4K, please download the service form from http://www.gigablue.de and fill it out completely.

GIGABLUE HD Quad Plus

Contents

Key Features Safety Instructions Notes: Disposal	4 5
Delivery content Front View	7 9
Digital Verstärker	_ 10
Start wizard 1	_ 11
Start wizard 2	_ 12
Start wizard 3	_ 13
Start wizard 4	_ 14
Start wizard 5	_ 15
Start wizard 6	_ 17
Start wizard 6	_ 18
Channel list install	_ 19
Turning on and off	_ 20
Program selection	_ 21
Volume / Audio selection	_ 22
Sub channels	_ 23
TV Radio Switch	_ 23
Teletext	_ 24
Subtitle	_ 24
Program Information's Program Information's EPG	_ 25 26
EPG	27
Create Bouquet	28
Add channels	_ 29 21
Move channels from the favorites list	רכ _ רכ _
Incort Marker	² د
Parental control	_ 33 _ 34
Lock Channels	_ 35
Lock Bouquets	_ 36
Protect settings Youth Protection HDD Operation	36 37
Commissioning of the HDD	_ 38
Sleep-Timer	_ 41 42
User mode	_ 42
Time zone	_ 44
Audio settings	45

Video output	45
Aspect ratios	46
Color format	46
AC3 Standard	46
Network settings	47
Network Settings	48
Network settings	49
WLAN Setting	50
WLAN setting	51
Factory reset	52
Channel search	52
Tuner Configuration	53
Channel automatic scan	54
Channel search DVB-C	55
Channel search DVB-T/T2	56
Rotor with USALS	57
Manual Scan	58
Fast scan	58
Unicable Configuration	59
Unicable Configuration	60
SAT Finder	61
Immediately Recording	62
EPG Recording	63
Timer	64
LED	65
Information	65
Software Update GigaBlue Box	67
Software Update via Internet	68
Software Update via Internet	69
Software Update via Internet	70
Install Firmware	71
Installing Extensions	71
PiP Picture in Picture	72
Extensions	73
User Interface / Basic Settings	74
Button allocation	74
User Interface / Skin	75
Weather	75
Position and Size	75
Web browser GigaBlue Box	/6
Web Interface	<u>//</u>
GigaBlue Player for Mobile devices	//
Problem-solving	/8
rechnical Specifications	79
Technical Specifications	80
Technical Specification	81
Universal Remote Control	82
Universal Remote Control	83

You can view the GigaBlue Box numerous UHD, HD, SD and IPTV programs that are broadcast via satellite and both via DVB-C / T / T2. This user manual explains how to install the GigaBlue Box and how to implement various functions. In addition, special functions are explained which are only available with the GigaBlue Box. This way you can make optimal use of these functions. The skin shown here is the so-called default skin. For other skins, only the graphical user interface changes, but the function remains the same.

Key Features

- Fully compatible with MPEG-2/4 and DVB-S / S2
- Resolution: 20160p,1080p, 1080i, 720p, 576p, 576i
- Digital Audio with AC-3 support by SPDIF
- User-friendly, on-screen menu system Linux
- Various channel editing functions
- (Favorites, Lock, Rename, Delete and Sort)
- · Automatic search for newly added transponders
- (automatic network search)
- · Easy and fast software upgrade via USB or Internet
- Timer function, automatic on / off with the appropriate setting of the function (once, daily, weekly and monthly)
- · Automatic system for moving bookmarked channels
- Electronic TV / Radio program (EPG)
- Video connectors: HDMI, RCA, COMPONENT
- RS-232
- · Different switch types, LNB types and NTSC / PAL monitor types
- SCPC and MCPC receivable from C / Ku band satellite
- Multi LNB controlled by DiSEqC 1.0, 22 kHz
- Automatic PAL / NTSC conversion
- · Last channel is automatically saved
- · Play multimedia files like MP3, videos and pictures in HD quality
- PVR on HDD or Network
- Media Portal, Streaming
- Timeshift (time shifting)
- Plugin Service (extensions)
- HDMI CEC control
- PiP (Picture in Picture)
- IP TV, IP Radio, Multistream
- Multiroom Systeme
- Hybrid Tuner
- SAT>IP
- Unicable
- Web Browser
- IP TV, IP Radio

This GigaBlue product was manufactured according to international safety standards.

Please read all safety and operating instructions before operating the product carefully and keep all safety and operating instructions in your records.

Safety Instructions

Setting up the GigaBlue Box

The GigaBlue Box may only be operated in closed rooms.

Power supply: External power supply 12 V 2 A

Outlets, extension cords or the power adapter must not be overloaded, since the risk of electric shock or fire could result.

• Liquids

The device must not come into contact with dripping or splashing. Do not place objects filled with liquids such as vases or glasses on the instrument.

Clean the GigaBlue Box

Before cleaning the GigaBlue Box from the power disconnect. No liquid or Use aerosol cleaners. Clean the appliance only with a damp cloth

Ventilation

the ventilation slots on the top of GigaBlue Box may not be covered, so that proper ventilation of GigaBlue box is ensured. Direct

Sunlight and installation in addition to a heating add to the GigaBlue box damage.

Connect the LNB's and TV

The GigaBlue box must be disconnected from the mains before you connect the LNB's or TV.

Repair or replacement

Opening or removing the covers of the user to dangerous voltages or other hazards may be suspended.

Repair or replacement may be carried out only by qualified technicians. Furthermore, void the warranty, the user should make changes to the GigaBlue box.

Notes: Disposal

The GigaBlue Box packaging consists entirely of recyclable materials.

Perform these exclusively that for you in your state, appropriate system.

The GigaBlue Box may at end of life not be disposed of with normal household waste but must be brought to a collection point for the recycling of electrical and electronic equipment.

The symbol on the product, the instruction manual or the packaging indicates.



The materials are recyclable according to their labeling.

By recycling, material recycling or other forms of utilizing old devices, you make an important contribution to environmental protection.

Please ask where the disposal facility is requested from your local municipality.

Also make sure that the dead batteries of the remote control and electronic waste from entering the household waste.

You are thereby making an important contribution to environmental protection.

Delivery content

Please verify that you have received the GigaBlue box complete with all accessories.

- GigaBlue UHD Trio 4K
- Power supply and cord
- GigaBlue Remote Control
- User Manual
- Batteries



GigaBlue UHD Quad 4K



Power supply



Batteries



Remote Control







User Manual

Remote Control Functions

0.	Battery Control LED					~
1.	Switching TV/Radio	0				20
2.	Giga , TV, Aux, DVD	1	TV/RAD	С С	MUTE -	 21
3.	Number field					 22
4.	Numeric keypad	2	GIGA		AUX	
5.	Red function Button					
6.	Green function Button, Plugin/Save			🖌 АВС	J DEF	
7.	Information on the receiving channel	3	• 4 вні	5 JKL	6 мно	
8.	Arrow button ◀ lift and ▶right					
9.	Channel list button ▲+ ▼-		7 _{PORS}	Вт⊔∨	9 _{wxyz}	23
10.	Select Audio button	4				 24
11.	Exit	5				25
12.	Volume ▲+ ▼ -	6				20
13.	EPG (Electronic Program Guide)	7	INFO		MENU	 27
14.	History button					
15.	Subtitels button					 28
16.	Aspect button	8				
17.	Timer button	0		UK		
18.	Control button reverse	0				
19.	Freely programmable button	9				~
20.	Power on/off	10	AUDIO		VIDEO	29
21.	sound on/off	11				
22.	Universal function TV/DVD/AUX			EXIT		
23.	Go back to the previous channel 0	12	-> VOL		СН	 30
24.	Numeric keypad 🕨			GIIIDE	\mathbf{N}	
25.	Timeshift start 🦳 💷	12				
26.	Bluepannel button	13	HISTORY			31
27.	Menu button				HDMI IN	 32
28.	OK button	15		ASPECT	TEXT	33
29.	Video button	10	TIMED			35
30.	Program ▲+ ▼-		TIMER	STOP	RECORD	
31.	Context button	18				 36
32.	Option channels	10		TIME SHIFT		31 20
33.	l eletext / Virtual keyboard	19	F1	PLAYLIST		30 30
34.	Stop button					
35.	Recording button					
30. 27						
ა/. 20	Pidy / Pause Timesniit ►					
30. 20	HDD Archivo button					
33.						

Caution: if GigaBlue remote GigaBlue Box not operated, please press the button GIGA

Front View



Inserting the smart card:

1. Hold the smart card horizontally so that the electronic chip points downwards.

2. Insert the smart card into the slot.

Power on/off	Turns GigaBlue box to standby
Menu	Opens the menu
Exit	Exits the menu / channel list
•	A channel back / Navigate menu
	A channel forward / Navigate menu
	Channel list Open / Navigating the Menu
V	Channel list Open / Navigating the Menu

Rearpannel



Antenna and TV Equipment

This chapter describes the installation of GigaBlue Box is explained. For information about installing external devices as, see below. As the satellite dish, LNB, refer to the corresponding manuals of the manufacturer. When installing a new appliance, the corresponding installation chapter in the manual must be observed.



Digital Verstärker

Die GigaBlue Box verfügt über einen optischen Ausgang. Damit können Sie den Digital Verstärker über ein optisches (LWL) Kabel verbinden.

Start wizard 1

Using the Startup Wizard, you can set up your GigaBlue box in a few minutes.

When you first start the GigaBlue you get the following Fig.1. Set the video output on. You have the ability to determine the outcome of the arrow keys $\blacktriangle \checkmark$ and press the OK button.

Then set the coding a, it can be reached with the arrow keys $\blacktriangle \lor$ and confirm with the OK button Fig.2.

In the next steps Langue: Then select with the arrow keys ▲ ▼ language Fig. 3 and press the OK button.

	HDMI
Video output (Resulation)	2160p für 4K TV 1080p 1080i 720p 576p 480p 480i



Fig.1 Fig.2 I:13 Video Wizard Auswahl des Videomodus. 720p 1080i 1080p 2160p 2160p 2160p 2160p 2160p 2160p 2160p 2160p



Start wizard 2

Next, the network is configured. Press **OK** to move to the next menu Fig.1.

Apply in Fig.2 the settings and click **OK**.

If you want to assign a static IP, press the arrow keys ◀► and set DHCP to NO. Now set the network so. That it

fits to your network

If you have chosen a wireless LAN, press the **OK** button WLAN configuration see page 50 and 51

Now your GigaBlue box for the first start is configured Fig.3. Click **OK** to close the installation.







Abb. 3

You will now be asked if you see the "See all eight arrowheads If you confirm arrowheads with OK, if not with the Arrow keys ◀► and set to no and press OK. Fig. 1

When arrowheads are not visible. Please first select left with arrow keys ▼ ▲ and adjust with arrow keys ◀ ▶ until you see arrowheads. Then right, up, down Confirm the selection with OK and you get to the next menu fig.3.



The Startup Wizard will now launch in your selected, Figure 1, Language and Video mode. With OK you get to the next point.



Der first Start

Start wizard 4

The start wizard is now started in your selected Fig.1, language. Press OK to move to the next point.

You will be asked if you want to make the basic settings (recommended) or want to quit the start wizard. Use the arrow keys ▲ ▼ to access the individual menu items. Fig. 2



Start assistant Tuner



The first Start

Start wizard 5

Then, if you have not finished the startup wizard, the tuner configuration will take place with the arrow keys ◀► you have the possibility of tuning the tuner to your Sat antenna or DiSEqC adjust. Fig.1 In the mode setting you have various choices possibilities



Fig.1



Fig.2







Fig. 4

Simple DiSEqC A/B DiSEqC A/B/C/D Rotor

(Will be described in detail) Singly

Toneburst A/B

Use the arrow keys **◄** the Configuration that suits your satellite System Fig.2 and press the OK button.

Tuner B:

First select the tuner C / T / T2 from Fig.3. The following options are available:

You can select the DVB-C or DVB-T / T2 tuner with the arrow buttons ◀► Fig.3.

DVB-C is for cable connection DVB-T / T2 is for terrestrial connection Select DVB-T / T2 and select country and region with the GREEN button. You can now start the search automatically or manually. Now switch to the reception menu and select Automatic search, start the automatic station search with the OK button. This takes some time Fig.4.

Der erste Start

Unicable:

The respective settings must be adapted to the SCR system. LNB 1 and LNB 2 are to be adjusted to the aligned satellite system. Here in the example it is 13 ° East (Eutelsat) and 19.2 ° East (Astra). Unicable must be selected under LOF. It should also be noted that the correct settings are made under Unicable configuration and manufacturer. If these preprogramed settings do not match the built-in components, then Unicable User defined must be selected. Under the menu item Diction that then appears, Unicable [EN50494] must be selected.

JESS:

The settings for JESS can only be changed in the Unicable User defined mode. Under the menu item Diction that then appears, JESS [EN50607] must be selected. The remaining settings, such as channel and frequency, must be made manually. The frequencies may only be assigned once for each connected tuner. Failure to do so will result in disorder.

Method:

Settings can be changed using the left / right directional pad.

See page 59 and 60

If you decide not to start a search at this time, then confirm this point with OK. Fig.1. If you would rather start a channel search, use the arrow keys ▼ ▲ to select whether you want to start an automatic or a manual search and then press the OK button and you will be taken to the next menu Fig. 2









The first Start

Start wizard 6

If you have opted for the standard channel list, press OK. Fig.1.

Would you rather start an automatic channel search, select with the arrow keys ▼ ▲ No and you move to the next menu Fig.2.

You can also install channel list later Plugin Server

After installing 2x Green button Under Setting, select the desired channel list and install



Fig. 1



The first Start

Start wizard 6

Confirm your selection with OK Fig.1.

The channel search will start.

This process takes some time to Fig.2.

After the scan with OK





Fig. 2

Start Wizard

Möchten Sie Jugendschutz auf der GigaBlue Quad Plus aktivieren?

Nein

Ja

Deutsch

OK / EXIT

Fig. 3

To activate youth protection YES with arrow keys ▼ ▲ Confirm your selection with OK

If no **NO** with the arrow keys ▼ ▲ confirm your selection with OK and move to the next menu Fig.3.

The first start

Channel list install

If you have decided not scan during GIGASLUE

Installation. You can install the channel list of the GigaBlue Server. Channel list has been programmed by our team for you 2x Green buttor with arrow buttons ▼ ▲ Settings and confirm your choice with OK Fig.1.

Search channel list, for example. GigaBlue 19e-13e with ▲ ▼ arrow keys Confirm with OK and the channel list will be installed. Fig. 2. After installing your channel list has been installed.



Fig.1.

wnloadable plugins
gigablue-19e (1.0+git5) Gigablue-19e (1.0+git5) Gigablue-19e-13e (1.0+git5) Gigablue-19e-13e-5e-75e (1.0+git5) Gigablue-19e-16e-13e (1.0+git5) gigablue-19e-16e-13e (1.0+git5) gigablue-29e-19e-13e-7e (1.0+git5) gigablue-29e-19e-13e-7e (1.0+git5) gigablue-29e-19e-13e-7e (1.0+git5) gigablue-29e-19e-13e-7e (1.0+git5) gigablue-29e-19e-13e-7e (1.0+git5) gigablue-29e-19e-13e-7e (1.0+git5) Gigablue-29e-19e-13e-7e (1.0+git5) Gigablue-29e-19e-13e-7e (1.0+git5) Gigablue-29e-19e-13e-7e (1.0+git5) Gigablue-29e-29e-29e-29e (1.0+git64) Hans-13e-19e-23e-28e (1.0+git64)
OK / EXIT

Fig.1.

Turning on and off

The GigaBlue box, you can turn on or off with the **power button**.

Please press briefly the **power button** to the GigaBlue box into standby mode to set, either on the remote control or at the Box GigaBlue directly. The display then the time is displayed.

If the power button on the remote control is pressed for 3 seconds. Long, goes the GigaBlue

Box in the Deep Standby mode.

Importantly this is no OSD menu is active.

This you can select the menu under **Standby / Restart** and select off in the **OSD**. Confirm with the **OK** button. The settings are saved and the

GigaBlue Box goes into deep standby mode. This means that the GigaBlue box is supplied with a minimum current. In this menu you get even if the **power button** is pressed for 3 sec.

In order to disconnect the GigaBlue Box from the power, put your box in the Deep standby and then press the Power switch on the back.

GIGABLUE	18:08 Standby / restart		
		Deep standby	
		Standby	
		Sleep timer	
	Restart enigma		
		Restart	

Program selection

Press the arrow buttons ▲ ▼ on the remote control GigaBlue Box it opens the channel list. Now navigate the arrow keys ▲ ▼ to the desired channel and press OK, it will be switched to that channel. RED Button to watch all Channels **GEEN** Button will be open Satellite List YELLOW Button will be open Satellite List Button will be open Favorite List **BLUE** GIGASLUE 22:25 Channel Selection **GEEN** Button will be open Satellite List Channel selection GIGABLUE 20:52 A Satellites Provider YELLOW Button will be open Satellite List EIEAELUE 21:12 Channel selection



BLUE Button will be open Favorite List



RED Button to watch all Channels



Volume / Audio selection

Use the arrow keys \blacktriangle \checkmark to adjust the volume with **VOL** \blacktriangle \checkmark to increase and to decrease the volume.

When you press the **MUTE** button, the sound is muted and an icon appears on the TV. Pressing the **MUTE** again

Mute the sound is switched on again and symbol disappears.

INFO	OK	MENU
	▼	
AUDIO		VIDEO
	EXIT	
	GUIDE	\mathbf{V}

In TV or radio mode, you can select the Audio / YELLOW button to the soundtrack of the channel.

			16:18 Dienstag 10 July 2012
	AC3		An
	Kanal		Stereo
	Zur Untertitel Aus	swahl	
	Audio Sync		
1	MPEG	stereo	*
2	MPEG	ohne Audiodeskription	
<mark>1</mark> 2	MPEC MPEC	stereo ohne Audiodeskription	×

Navigate with the arrow keys ▲ ▼ to the desired track and press the **OK** button.

The content of this menu depends on the selected channel.

Sub channels

If you are on a channel which broadcasts sub channels, such as Sky, you may select this with the **GREEN** button.

\bigcirc	Schnellumschalter
	Zum Bouquet hinzufügen
0	Sky Select
1	357 - 20:30
2	357 - 21:00
3	420 - 20:30
4	420 - 21:00
5	496 - 20:30
6	496 - 21:15
7	482 - 20:30
8	497 - 20:30

When pressing the **OPT (option)** in TV Mode, you see a list of Sub channels. Move the ▼ ▲ keys to the desired Sub channel and confirm with OK.

Use the arrow keys ◀► to switch to the next sub channel

TV Radio Switch

With the **TV / RAD** button, you enter the radio mode. You can leave it again with the **TV / RAD** or **EXIT** button.

You can also see at the bottom of the current and next program.

GIGABLUE	2:16	Chanr	nel selection			
		Ch	annel selection (Rac	dio) - User - bouquet	S	
	≡نين≡		ASTRA Favourites (Radio)			
		All	Satellites	Provider	Favourites	MENU

Teletext

With the **TXT** button to enter the teletext display this you can leave with **EXIT** button. Select the corresponding your page. The assignment of the below

Keys can be different, as the Teletext is transmitted. The display of the function is displayed on the bottom of the screen.

RED	Button
GEEN	Button
YELLOW	Button
BLUE	Button

At a break, use the numeric keypad on the remote control.



Subtitle

When the teletext symbol appears on the menu are available subtitles (channel-dependent).

Program Information`s

Program Information's

When a program changes you receive the following information in the lower part.

This is on the OK button repeatedly accessed.



EPG of GigaBlue Box

Program Information's EPG

By pressing the **INFO** button can From the running TV program Information about the film / consignment learn. By pressing the arrow keys ◀► you get information about the next shipment. By pressing the **YELLOW**, **BLUE** or **RED** key to access the simple EPG of the transmitter or Multi EPG. Will be described below Fig.1.

Here in simple **EPG** you get Information rundown of Channel. You can press the **YELLOW** key to A-Z or time sort. Navigate with the Arrow keys ▲ ▼, when you press the **INFO** button to get information for each program Fig.2.

If you select **multiple bouquets** (**Page 44**) allow to put yes who appears as the first one Selection of bouquets. Decide You are interested in the bouquets for you a Multi EPG to display. You now get an overview of the current channels.

Links will of history Broadcast graphed. In the right column shows the name of the channel. With the **OK** button you will receive Information on the individual Broadcast.

Navigate with the arrow keys

▲ ▼ to your channel and press the **RED** button to access this channel to Change Fig.3.



Fig.1





EPG of GigaBlue Box

EPG

Here you get an overview of the subsequent broadcasts. You can add entries up to a week to see (transmitter dependent). Furthermore, you can use the timer function here.

Press the **GREEN** button Fig.1 You can set the timer and the Timer Menu. Here you record and change the selection. Furthermore, you can daily, weekly, put Mon-Fri, and custom timers.

To accept, press the **GREEN** button. Now you can see that the timer for the program has been set. Fig.2

	GIGABLUE	1:36	EPG Sele	ection			15°∽	22 °C 12 °C	<i></i>		
				OHD D)as Erste HD						
				Mon	13.07, 00:50 Ta	age und Wolken					
				Mon	13.07, 02:48 Ta	agesschau					
				Mon	13.07, 02:50 In	nspector Mathias - M	Mord in Wales: Die	Brücke de			
				Mon	13.07, 04:23 Ta	agesschau					
				Mon	13.07, 04:25 D	eutschlandbilder					
			Mon	13.07, 04:48 Ta	agesschau						
			Mon	13.07, 04:50 W	Veltspiegel						
•				Mon	13.07, 05:30 A	RD-Morgenmagazir	n				
				Mon	13.07, 09:00 Ta	agesschau					
				Mon	13.07, 09:05 R	ote Rosen (1995)					
				Mon	13.07, 09:55 St	turm der Liebe (225	i9)				
				Die Kunstł	historikerin Elsa ist	noch verkatert von	i der rauschenden F	eier ihrer			
				bestanden	nen Promotion, als	ihr Mann Michele k	leinlaut erklärt, er s	ei			
				arbeitslos	und pleite. Der soz Hals über Konf mü	ziale Abstieg des sci issen die beiden ihr	heinbar wohlhaben re kostspielige	den Paares	5		
				Eigentums	swohnung aufgebe	n und in ein Hochh	aus ziehen. Währen	ıd Elsa sich			
			700		Add times	Court A 7	Course				
2			Zap		add umer	Sort A-2	search		MENU		

Fig. 1 GIGASLUS 1:38 Timer entry 15 0 6 er type 13.luly 2015 00:47 02:53 te HD Location After event auto Recording type ormal 1.::/abc2ABC def3DEF jkl5JKL ahi4GHI mno6MN0 pgrs7PQRS tuv8TUV wxyz9WXYZ 0,?!&@=*'+"()\$~

Fig. 2



Create Bouquet

What is a bouquet and what can that mean?

When you open your browser, you will definitely have websites that are visited by you, they have you determined your favorites stored under a folder to start it later quickly. The principle at the bouquet is exactly the same. Do you want to have all your sports channels in a folder? Create a bouquet and copy the individual channels into the bouquet. Must be to create the bouquet option under **Customize** on Several Bouquet allow set to **YES** (page 44). **Create Bouquet** is described below.

Note: Channels can be erased only in the Favorites view. Channels in the All cannot be deleted. This serves the purpose of which there is a list of the always all channels. If you will perform a search, all channels are all stored in the view. Your previously created

bouquets, remain unaffected. Press the arrow buttons \blacktriangle \checkmark on the remote control. This opens the channel list. Then press the **BLUE** button **FAVOURITES** Fig1. Now press the **Menu** button and you will see the channel lists menu Fig.2. Please choose **add bouquet** Assign the name for the new **bouquet**, in our case, test Fig.3. Confirm with **OK** and you will see your created Bouquet Fig.4. To create additional Bouquet proceeds

as described above.





Add channels

You can add from the **All**-, **Satellite**- and **Providers view** list the channels to your favorites list. By using the **RED**, **GREEN** and **YELLOW** button, go to the respective menu. We explain the add reference to the previously created test bouquet and by all views of multiple channels.

Press the arrow keys $\blacktriangle \lor$ This takes you to the channel list, select a channel from the one bouquet you want to add, for example, Das Erste. Next, you press the Menu key, select item to **add bouquet**.

Select the bouquet created (in this case, German HD) and presses the **OK** button, the selected channel is added to the bouquet. Fig.3

When you add more channels, proceed as follows.

Go to your created bouquet (in this case, German HD), press **Menu** button.

Navigate to enable the arrow keys ▲ ▼ to the point **bouquet edit confirm** with **OK** Fig.4.

This takes you to the channel list.









Quit now Bouquet Editor Fig.3 mode by pressing the OK button. All channels previously selected are now in the bouquet. Proceed with the other bouquets in the same order.

bouquet Fig.2.





Operation Network Settings

Delete channels from the favorites list

Use the arrow keys \checkmark \blacktriangle to enter the channel list. Press the **BLUE** button to display in your favorites list, and then select the bouquet of where the channel is to be deleted. Select the desired channel for deletion Fig.1.

Press the Menu and select **Remove entry from** Fig.2 confirm **OK** and the channel from the list away Fig.3.



Fig.1



Fig. 2



Fig. 3

Move channels from the favorites list

Use the arrow keys \checkmark \blacktriangle to enter the channel list. Press the **BLUE** button to display in your favorites list, and then select the bouquet of where the channel is you want to move.

Press the **Menu** button and select **Activate move mode**, you press **OK** Fig.1 Now proceed with the arrow keys ▲ ▼ to the channel you want to move, Select channel by pressing the OK button Channel is highlighted in **RED** Fig.2.

Now move the channel to the desired location

and press the **OK** button Fig.4. If all the channels on the desired location are pressing the Menu key and exit the **Move mode** Fig.5. Now move the channel to the desired location and press the OK button Fig.4. If all channels are at the desired location, press the Menu key and exit the Move mode Fig.5.Now move the channel to the





Fig. 2





Fig. 4



Insert Marker

Use the arrow keys \checkmark \blacktriangle to enter the channel list. Press the **BLUE** button to display in your favorites list, then select the bouquet from where you want to insert a marker. Navigate to the location where the marker is to be placed. The marker will be added above the selected channel.

Press the Menu key and select Insert markers confirm with **OK** Fig.1.

Enter the marker name. Please fill in the numeric keypad; it can be used numbers and letters Fig.2. When you are finished, press the **OK** button and the marker will be dropped Fig.3.



	Fi	g. 1										
	Virtual KeyBoa	ard										
Please enter a name for the new mark				ker								
6												test
000000	EXT I	1	2	3	4	5	6	7	8	9	0	←
	q	w	е	r	t	у	u	i	0	р	-]
	а	s	d	f	g	h	j	k		;	•	
	<	z	x	с	v	b	n	m			1	ALL
	Ŷ		oĸ	÷	+	*						
	Fiç	g. 2										



Parental control

Setting the protection of minors

This describes how the protection of minors will be activated and set at the GigaBlue box.

Go into the **Settings menu** and select **parental protection** from Fig.1.

You can now choose positive or negative list. The positive list means that any non-parental control list added channels will be blocked.

The negative list, however, means that all of the added to the parental control list will be locked.

Change Pin code

If you want to change the PIN code press OK Fig.1.

You are prompted first to enter the old PIN is 0000. in the ground state Fig.2

Now enter the new PIN and repeat it Fig.3.

Were different pins enter the message in Fig.4, otherwise if everything was entered correctly, the message appears in Fig.5 and confirm with **OK**.



Fig. 5









Parental Protection

Lock Channels

Go into the **Setup menu** and select **parental protection / protect services** and change to **YES** use the arrow keys ◀► Fig.1. You can now choose positive or negative list. The positive list means that any non-parental control list added channels will be blocked.



Lock Screens

Go into the **Setup menu** and select **parental protection / protect screens** and change to **YES** use the arrow keys **◄** Fig.1. You can choose which want to lock menu.

To lock **YES** select, use the arrow keys **◄**► Fig.1.

Lock Channels

Now go **to Channel List** Press Menu button and go to **add to parental protection** to lock channels and press **OK**. Fig.1

Press the **OK** button and the station will be provided with a lock Fig.1. If you want to lock multiple transmitters proceed as described.

Press the EXIT button and accept the settings with the GREEN button.

Will now try the protected channel Open will be asked for the PIN code Fig.2. You have to 3 attempts, the Pin 3 should times are entered incorrectly, you will need 15 Minutes wait until you try it again can







Bedienung der GigaBlue Box

Parental Protection

Lock Bouquets

Now go to Channel List / Bouquets (Blue button) Press Menu button and go to add bouquet to parental protection to lock bouquets and press OK. Fig.1

Channellist me	enu 12 ° 🖒 🔢 🤅 👸
	 Configuration add bouquet to parental protection add bouquet rename entry remove entry enable move mode Reload Services



Protect settings Youth Protection

If parental controls are protected, this point must be set to yes, then after entering the pin's in the Parental menu Fig.1.


HDD Operation

You have the option at the box GigaBlue an external hard drive to the USB port or to connect to the internal e-SATA. It is automatically detected. You can record programs, take pictures, music and the media player (must be installed optionally) play.

Commissioning of the HDD

Change to the menu / Setup / System / Device / storage devices Fig.1.

Devices	
	Storage media
	Keyboard
	Input devices
	HDMI-CEC



HDD Operation

Commissioning of the HDD

You can adjust the behavior of the HDD in standby mode. Abb1.

The following settings are available:

No standby 10,20,30 minutes 1,2,3,4 hours

Select your setting and this with the **GREEN** Button from Abb1.

Next, the HDD initialize (format) has to be, select this item and confirm with **OK** Fig.2.

Now select your hard drive and confirm with the **OK** button.

With the **RED** button to start the initialization process Fig.3, this may take some time.







Fig. 2



Fig. 3

HDD Operation

Commissioning of the HDD

If you ever have the feeling that you're hard drive something should not be in order, so they can use the

File system check test Fig.1. Confirm with **OK** and start the program with the **RED** button Fig.2.







HDMI CEC

HDMI-CEC

Menu/Setup/System/Devices/HDMI-CEC

With the arrow keys ▲ ▼ ◀► you can switch on HDMI-CEC and with the YELLOW key specify the address and save with OK Important Turn on HDMI-CEC also with your LCD TV.

HDMI CEC

With the help of the HDMI CEC (Consumer Electronic Control) standard you can connect devices that are connected via an HDMI cable and this standard

support, with a remote control. If your TV set has the HDMI CEC standard, your TV will automatically switch on / off when you switch the receiver on / off.



	GIGASLUS	01:24:33	HDMI-C	EC Configuration	13° 🖒	18°C 🎝
f				Eingeschaltet Fernseher aus Standby versetzen Deep-Standby wie Standby abehandeln Fernseher auf Receiver HDMI-Eingang schalten Fernbedienungsbefehle des Fernsehers weiterleif Receiver mit Fernseher in den Standby versetzen Receiver mit Fernseher aufwachen Anschaltsignal vom Fernseher	en	ja ja Ja Nein Nein Ja Ja Stream Anfrage
	KE	ini EC		Lautstarketasten weiterietien AV-Receiver in den Standby versetzen AV-Receiver aus Standby anschalten Sendeintervall Mininum		Nein Nein Deaktiviert
				Aktuelle CEC-Adresse: 2.0.0.0		
			Abbrechen	OK Adresse fest	Neue Adress	e EXIT

Sleep-Timer

Press the Power button on the remote for 3 seconds Abb1 and click OK.

Here you have the following options by pressing the keys mentioned Fig.2:

RED button Enable / Disable

GREEN button switch of / Standby YELLOW button demands Yes / No

BLUE button time off the current Take over Program

If you have made all settings, press the OK button and the following message appears



Fig. 1

GIGASL	.ii≡	2:10	SleepTimer C	onfiguration		<mark>/</mark> 12° 🖒	22.°C 13.°C
	Sleeptimer Inactivity S Shutdown	(not activate leeptimer when in Stan	d) dby			Star	dby in 30 minutes Do nothing Disabled
2	Configure t sleeptimer	he duration	n minutes for the sleep	ptimer. Select this e	entry and click OK (or green to start/stop	b the
				Cancel	/	Save	OK EXIT
				Fia. 2			

Operation Language selection

Language selection

Go to the menu

Setup / System / User interface / language

There will be different languages to choose from shown Fig.1.

GIGASLUS	23:54	Languag	ge selecti	on	 13° 🖒	18 °C 10 °C ÖÖ
				Arabic		
				Български		
				Català		
				Česky		
				Dansk		
	Č)			Deutsch		
			±==	Ελληνικά		
				English		
			<u>.</u>	Español		

User mode

Go to the menu Setup / System / Basic settings.

Here you can use the modes

Easy Advenced Experte

Adjust. If the individual yet described.



Operation User mode

User mode

Easy Modus

Margin before record (minutes):

Here you can set the lead time for timer recordings in minutes.

Margin after record:

Here you can set the delay time for timer recordings in minutes.

Show blinking clock in display during recording:

Here you can select whether the OLED display while recording the clock to display flash.

Infobar - Display time:

Specify how long the info bar will be displayed, a maximum of 10 seconds.

Advanced Mode:

Additional settings for Simple mode.

Recordings always have priority:

Here is the option chosen Yes, the system automatically switches to a timer recording conflict on the station to be recorded.

If the option is set to No, you are asked if you want to switch on the channel to be recorded.

Show positioner movement:

Is your satellite system equipped with a rotor, on the TV, a flashing symbol of an antenna is shown, unless you have asked the option to Yes.

Multi bouquets:

If you want to use more than one bouquet you set this option to Yes.

Change bouquets in Quickzap:

If this option is set to Yes, automatically at the end of the bouquet changed to the next bouquet.

Alternative radio mode:

If this option is set to Yes, the GigaBlue Box behaves just as in TV mode.

Action on long press on Power:

When long press the **power button** the following options are given: **Show shutdown** or **immediate shutdown**.

Operation Time zone

Time zone

To set the time zone change to the menu

Setup / System / Basic settings / time zone with the arrow keys ◀► to adjust the time zone with the GREEN button to accept or discard the RED button Fig.1.

Setup		13°C 🗘 18°C	Ö
	Timezone Sync time using NTP server Sync NTP every (minutes)	(GMT+01:00) Amsterdam, Berlin, Bern, Rome, Vienna Transponder Time pool.ntp.org 30 minutes	
	Cancel	ОК	EXIT

Video settings

Here you can make the settings on the audio and video settings.

To make settings on the Audio / Video switch to the menu, Setup / Video / Basic Settings

Now select th from the follo	ne resolution you want to use wing options according to	GIGAELLIE	23:31	Setup		13° 🖒 🔢	Ő
the video out	put and your TV selected				Video output	HDM	11
above.					Mode Defreek rete	1080	p
					Display 4:3 content as	mui lust scal	u
					Display >16:9 content as	Just scal	e
					OSD transparency		
					Scaler sharpness		
	HDMI 2160p				Bypass HDMI EDID Check	đ	ff
Auflösung	1080p 1080i 720p						
	576p				Cancel	ОК	EXIT
	480p 480i						

Operation Audio/Video Settings

Audio settings

Here you can make settings on the audio and video settings. To make settings on the Audio / Video switch to the menu, Setup / Audio / Basic Settings

Setup		13°C 🐣 🕺	Ö
	AC3/DTS downmix AAC downmix AAC transcoding General AC3 delay General PCM delay 3D Surround Audio Auto Volume Level	yes off 0 0 off off	
	Cancel	ОК	EXIT

Video output

Video output:

This determines where the video signal to be output. The options are:

HDMI

YPbPr

Use the arrow keys to select $\blacktriangleleft \blacktriangleright$ die desired output.

Modus:

The following options are available:

PAL

NTSC

Make this a country-specific. Use the arrow keys $\blacktriangleleft \triangleright$.

Refresh rate:

In normal TV devices only options 50Hz, 60Hz and Multi are available. If your TV is connected via HDMI or YPbPr you can vote the interface screen for your TV device.

Operating Audio / Video Settings

Aspect ratios

Modus 16:9

Pillarbox:

Just Scale:

Nonlinear:

The outer portion of the image is slightly distorted, so, a perfect image is shown in the inner area, in full screen mode.

Pan&Scan:

Modus 16:10

Color format

The following formats are available: RGB (RED, GREEN, BLUE) CVBS (Separated color and luminance signal) Select the appropriate format.

AC3 Standard

Set here whether AC3 should be on or off. Use arrow keys ◀►.

Network settings

Go to the menu Setup / System / Network / Basic Settings to configure your network to Fig.1.

If a DHCP server on your network, you can change the settings to take Fig.2. Use the arrow keys ◀► to a Static address assigned Fig.3. Save Press the OK button the settings.Abb.1



Fig.1



 Image: State Stat

Network Settings

The following options are available:

Enable Network Adapter:

You can disable or enable the adapter for a wired network. Address automatically (DHCP): Determine whether the network address is automatically obtained from a DHCP server.

IP Address manually assigned.

Do you want to assign the IP Address manually to set the DHCP server on No. Now enter the IP address (that matches your network pool), and the network mask (**default setting 255.255.255.0**).

After that it's important to also set the gateway to **YES**, you now assign the gateway address. See figure. Accept the input by pressing the **OK** button.



DNS-Setting:

Next, enter the DNS address and save with OK. See figure.

Na	ameserver 1	<mark>192</mark> 168.160.25	94
Pre	ess OK to activate the settings.		

Network settings

After successful network setting you can check this.

	Netwo	ork test: LAN connection	/ 12	°C 22 °C 13 °C	Ö
		LAN adapter LAN connection	/	Show info	
		Local network connected	/	Show info	
		DHCP enabled	/	Show info	
	IP address confirmed	/	Show info		
	Nameserver confirmed	/	Show info		
		Edit settings			
		Close Restart	test		EXIT

The test is started with the **GREEN** button.

GREEN means successfully **RED** unsuccessful. As the DHCP is disabled and no approvals for the internal network are available they are displayed in **RED**. To exit, press the **RED** button.

Restart Network:

With this option, you can restart the network configuration of your GigaBlue box.

Network Assistant:

The network wizard will assist you in the settings of your network.

Release Manager See pages

Networkbrowser See pages

Connect renewed Connects network renewed

Network Assistant Network Assistant will be restarted

MAC-Settings Please do not change macaddress, MAC address has been saved in the HW

Enable/Disable IPv6 This will enable IPv6 protocol.

Go to Menu / Setup / System / Network Abb1.

Now go to wireless connection and click OK to confirm Fig.2

WLAN setting



Fig.1



Fig.3

Now activate the Wi-Fi adapter, Fig.3,

Use the arrow keys **◄** ► confirm with **OK**. Now, the wireless network is enabled. This may take several seconds

WLAN setting





 CIEAELLIE
 0:14
 Virtual KeyBoard
 13 ° C
 Inc C

 Image: Constraint of the second state of the second stat

Fig.6

Now activate the **Wi-Fi adapter**, use the arrow keys **◄** confirm afterwards with **OK**. Fig.5, Select encryption WPA and WPA2 Then enter your security key. Fig.5. With the **TXT** button to enter the Virtual Keyboard Fig.6 After entering confirm with the **GREEN** Button

Now you press the **OK** button to save Wlan This may take a few seconds. and start GigaBlue new. Now the wireless network should be available to

Factory reset

Factory reset:

Menu / Setup / System / factory reset

Here is the GigaBlue Box to their original initial values. Here lose all the settings you have made.

Click OK to confirm that GigaBlue Box leads after restart

GIGA∃LUE 23:19 System	
	User interface
	Frontpanel
	Recording
	EPG
	Network
	Devices
	Basic settings
	Software management
	Factory reset

Channel search

Menu (Setup / tuner / tuner configuration (Basic Settings) Here you have several options:



Tuner Configuration

A single satellite - direct connection

You need this satellite configuration if you only want to receive a single satellite position with a single universal LNB. The coaxial cable is connected directly to the LNB and the GigaBlue. Follow the steps below Navigate with the arrow keys ▲ ▼



Menu / Settings / Tuners / Basic settings / Tuner configuration select Tuner and press the OK button

Navigate to Mode with arrow keys ▲ ▼, navigate to Individual with arrow keys ◀►. Navigate with the arrow keys ▲ ▼ to satellite. Use the navigation keys ◀► to select the desired satellite. Now save with the OK button

Setup tuner		/ 2	23 ~ 🔿	16°C Q
Kont Port Port Spar Dise	figuration Hz A B nnung und 22KHz setzen iqC nur bei Sat-Wechsel senden	13.0	19.2E Astra 1K IE Eutelsat Hot Bird 1	Einfach DoseaC A/B R/1L/1M/1N 38/13C/13D Ja Nein
Abbrechen	Speichern K	onfiguration		EXIT

Two satellites via DiSEqC A / B

You need this satellite configuration if you want to receive two satellite positions via a Twin Universal or Quad Universal LNB for four or eight or more participants or end devices. It does not matter whether the LNBs are attached to a separate mirror or a single mirror, so-called "squinting".

In this case, the LNBs are connected to a so-called multiswitch or to a DiSEqC. The individual coaxial cables then go from this multiswitch or DiSEqC to the participants or end devices (GigaBlue). Follow the steps below

Menu / Settings / Tuner / Basic settings / Tuner configuration select Tuner and press the OK button

Navigate to mode with arrow keys $\blacktriangle \lor$ Navigate to DiSEqC A / B with arrow keys $\blacktriangleleft \triangleright$. Navigate with arrow keys $\blacktriangle \lor$ to port A and B Use the navigation keys $\blacktriangleleft \triangleright$ to select the desired satellite. Now save with the OK button

Four satellites via DiSEqC A / B / C / D

You need this satellite configuration if you want to receive four satellite positions via a single universal or twin universal LNB for four or eight or more participants or end devices. It does not matter whether the LNBs are attached to a separate mirror or a single mirror, so-called "squinting". In this case, the LNBs are connected to a so-called multiswitch. The individual coaxial cables then go from this multiswitch to the participants or end devices (GigaBlue).

Follow the steps below

Menu / Settings / Tuner / Basic settings / Select tuner configuration and press OK button Use arrow keys ▲ ▼ to navigate to mode

Use arrow keys $\blacktriangle \lor$ to navigate to mode Use arrow keys $\blacktriangleleft \triangleright$ to navigate to DiSEqC A / B / C / D. Navigate with the arrow keys $\blacktriangle \lor$ to port A, B, C and D Use the navigation keys $\blacktriangleleft \triangleright$ to select the desired satellite. Now save with the OK button

Channel automatic scan

Menu (Setup / Tuners / Automatic scan)

Important **!! Tuner must be configured, see page 17.** Fig.1.

The following options are available: Fig.2 This can be reached with the arrow keys \blacktriangleleft .

Network scan: Yes / No

Clear before Scan: Yes / No: Caution, if you will indeed select automatically delete the existing channel list.

Scan Tuner A (DVB-S2): Yes / No

Now start the **OK** button to automatically scan channels. This takes some time to Fig.2. Upon completion of the search, you exit the menu with the **EXIT** Button, the stations found are now available.

Proceed with the other options on the same procedure.





Fig.2



Channel search DVB-C

If you have a GigaBlue C / T Tuner have installed, please following Make settings. First, select the tuner C / T in Fig.1. The following options are available:

You can also DVB-C or DVB-T tuner with the arrow keys ◀► Select Fig.3.

DVB-C for cable DVB-T is for connection Terrestrial Select DVB-C and save with the **GREEN** button Fig.2. You can now search start Automatic or Manuel.

Now switch to the reception menu and select Automatic Search, start with the **OK** button to automatically scan channels. This takes some time to figure 3.

Upon completion of the search, Exit the menu with the **EXIT** button the stations found are now available.

Proceed with the other options to the same procedure





Abb.2



Abb.2

Channel search DVB-T/T2

If you have a GigaBlue C / T Tuner have installed Please following Make settings.

First, select the tuner C / T in Fig.1. The following options are available:

You can also DVB-C or DVB-T tuner with the arrow keys ◀► Select Fig.3. DVB-C for cable DVB-T is for connection Terrestrial Choose DVB-T and store it with the **GREEN** button Fig.2. You can now search start Automatic or Manuel.

Now switch to the reception menu and select Automatic Search, start with the **OK** button to automatically scan channels. This takes some time to figure 3. Upon completion of the search, you exit the menu with the **EXIT** Button, the stations found are now available. Proceed with the other options to the same procedure.



Tuner-Wahl

- Empfang A: BCM7346 DVB-S2 NIM (internal) (DVB-S2) DISEqCA/B Satelliten: 19.2E Astra 1KR/1L/1M/1N, 13.0E Eutelsat Hot Bird
- Empfang B: BCM7346 DVB-S2 NIM (internal) (DVB-S2) Verbunden mit Empfang A
- Empfang C: GIGA DVB-S2 NIM (ST) (DVB-S2 Gleich wie Empfang A

Empfang D: GIGA DVB-C/T NIM (SI) (DVB Umschaltbare Tuner-Typen:(DVB-T,DVB-C)





Abb.3

Rotor with USALS

Menu (Setup / tuners / tuner configuration

Please select with arrow keys ◀► rotor

Enter here the geographic data of your location longitude and latitude, this, see, for example, http://www.heavens-above.com.

The GigaBlue Box does the rest for you when you select a satellite or change the channel. The system developed by the company staff calculation module USALS, turns your satellite system with an accuracy of 0.1 degrees on the respective satellite fully automatically.

Setup t	tuner	<mark>/</mark> 16° 🦽	30 °C Č
	Configuration mode Mode Longitude Latitude Extra motor options		Simple Positioner 005.100 East 050.767 North no
Cancel	Save	Configuration mode Set defai	ult EXIT

Rotor without USALS

Navigate with the arrow keys ◀► Advanced. Now navigate the arrow keys ▲ ▼ to DiSEqC mode and select 1.2. Now go use the arrow keys ▲ ▼ to the point USALS for this satellite and set it to NO. Now move with the arrow keys ▲ ▼ to stored positions and give the above-mentioned position is stored in the rotor. These can be found in the rotor manual.

🦲 Tune	Auto fo	icus	Calibrate	Calculate
	Tune and fe	ocus		
	Movement			
	Set limits	nent		
	Memory in	dex		
	Goto			0.000
				East
0.	00 dB			
SNR:		096	Frequen	cy:
BER:			Polarisat	ion: Horizontal
Lock: not loc	ked		Symbol r	ate:
				0 234

Manual Scan

Menu (Setup/Tuners/Manual scan

Go with the arrow keys $\blacktriangle \lor \blacklozenge \lor$ and **Manual Scan.**

Use the arrow keys $\blacktriangle \lor \blacklozenge$, select and enter information via satellite, frequency, symbol rate, etc. Please start the search with **OK**.



Fast scan

Menu(Setup/Tuners/faster scan

Go with the arrow keys $\blacktriangle \lor \checkmark \checkmark$ and faster scan. Choose OK to confirm Use the arrow keys $\blacktriangle \lor \checkmark \checkmark \checkmark$, select and enter the information via satellite, provider, HD, etc. Please start the search with OK.



Unicable GigaBlue Box

Unicable Configuration

Unicable LNB

Menu -> Setup -> Tuners -> Basic setting -> Choose Tuner

Configuration mode -> Advanced Satellit -> Select a satellite (for example,Astra 19.2°E) LNB -> LNB1 Priority -> Auto LOF -> Unicable Unicable Configuration -> Unicable LNB Manufacturer -> Manufacturer of LNB Type -> Type of LNB Channel -> select one of the 4 channels Frequenz -> is permanently linked with the channel and cannot be changed here

52 Setup	tuner	16 °C 👌 📅 🖄
	Configuration mode Satellite Priority LOF Unicable Configuration mode Manufacturer Type Channel Frequency connected DISEqC mode	Advanced 19.2E Astra 1KR/1L/1M/1N UNB 1 Auto Unicable / JESS Unicable / JESS Unicable LNB inverto IDLB-QUID-UNI2L-OPP SCR 1 no None
Cancel	Save	Configuration mode Set default

Unicable house wiring with Unicable multi-switch on a satellite

Menu -> Setup -> Tuner -> Basic setting -> Choose Tuner

Configuration mode -> Advanced Satellit -> Select a satellite (for example,Astra 19.2°E) LNB -> LNB1 Priority -> Auto LOF -> Unicable Unicable Configuration -> Unicable Matrix Manufacturer -> Manufacturer of Matrix Type -> Type of Matrix Channel -> select one of the 4 channels Frequenz -> is permanently linked with the channel and cannot be changed here

Setup	tuner	- 16°C 会 30°C 谷
	Configuration mode Satellite LNB Priority LOF Unicable Configuration mode Manufacturer Type Channel Frequency connected DISEqC mode	Advanced 19.2E Astra 1RR/1U/1M/1N LNB 1 Auto Unicable / JESS Unicable Marixe IDLP-USS200-CU010-3EP SCR 1 1025 no None
Cancel	Save	Configuration mode Set default

Unicable GigaBlue Box

Unicable Configuration

Unicable house wiring with Unicable multi-switch on two satellites (Astra / Hotbird)

Menu -> Setup -> Tuner -> Basic setting -> Choose Tuner

Configuration mode -> Advanced Satellit -> Select a satellite (for example,Astra 19.2°E) LNB -> LNB1 Priority -> Auto LOF -> Unicable Unicable Configuration -> Unicable Matrix Manufacturer -> Manufacturer of Matrix Type -> Type of Matrix Channel -> select one of the 8 channels Frequenz -> is permanently linked with the channel and cannot be changed here



Satellit -> select the second satellite

(e.g. Hotbird 13.0°E) LNB -> LNB2 Priority -> Auto LOF -> Unicable Unicable Configuration -> Unicable Matrix Manufacturer -> select the same manufacturer as for the first satellite Type -> choose the same type as for the first satellite Kanal -> Select the same channel as for

the first satellite Frequenz -> is permanently linked with the channel and cannot be changed here

Unicable with any exotic parameters

Menu -> Setup -> Tuner -> Basic setting -> Choose Tuner Configuration -> advenced Satellit -> select the first satellite (zB. Astra 19.2°E) LNB -> LNB1 Priority -> Auto LOF -> Unicable Unicable Configuration -> Unicable User defined Here you can choose all parameters free itself.





If more than one tuner available, so each tuner must be assigned its own channel

Satfinder GigaBlue Box

SAT Finder

By Satfinder you can easily adjust your antenna.

Menu (Setup / Tuners / Signal Finder with OK. Abb1

GIGAELUE	0:03 Tuner	┃ 16 °C 〇 23 °C 送
		Basic settings
		Automatic scan
		Manual scan
		Fast Scan
		Blind scan
		Positioner
		Satfinder
	Fig.1	

You can change the arrow keys to satellites and transponders. Fig.2



Fig.2

Immediately Recording

The prerequisite for this is that a network HDD or external HDD is connected to the USB port and set up see pages 37 to 39., An instant recording is started by pressing the **Record** button, it opens to see the menu as shown in Fig.1. You are now 5 options for selection see Fig.1.

- 1) Add recording the current program.
- 2) Add Recording indefinitely
- 3) Add Recording enter recording duration.
- 4) Add Recording enter recording endtime.
- 5) Do not recording

Move with the arrow keys $\checkmark \blacktriangle$ to the appropriate selection and click **OK** to confirm.

To stop recording, press the **Record** button and move with the arrow keys $\checkmark \blacktriangle$ to the corresponding selection Punk 8, and then click **OK**. Fig.3

If multiple records have been started, which lie on the same transponder, you will be offered a choice.

You can further broadcasts recording lying on the same transponder, or even watching Fig.4, the channels are not available are **grayed** out.





Fig.2





Immediately Recording

To determine which transmitter is available to open the channel list with the arrow keys ▲ ▼ here is displayed which channel can be recorded or viewed Fig.1.



EPG Recording



Please press **INFO** button **long**. You have on the screen EPG of the current channel Select the program you want to record and confirm with the **GREEN** button **Timer set** Fig.1.

Set the guidelines as a should proceed GigaBlue box.

Then press the **GREEN** button to launch Settings to accept Fig.3.



Fig.2 EPG Selection GIGABLUE 1:40 15° ∽ OHD Das Erste HD 13.07, 02:50 🌒 Inspector Mathias - Mord in Wales: Die Bri 13.07, 04:23 Tagesschau 13.07. 04:25 Deutschlandbilder 13.07, 04:48 Tagesschau 13.07, 04:50 Weltsp 13.07, 05:30 ARD-Morge 13.07, 09:00 Tagessch 13.07 09:05 Rote Rosen (1995) 13.07. 09:55 Sturm der Liebe (2259 Fig.3

Menu / Timer

Here you have several options Auto Timers Record Sleep Timer Open the main **Menu**, use the arrow buttons ▲ ▼ in **Timer** (timer) and press the **OK** button Fig.1

Autotimer Fig.2

Add With the **BLUE** button and select Bouquet program you use the arrow buttons ▲ ▼ in timer (Timer) and confirm with the **OK** button Now you can choose the program and confirm with the **GREEN** button





Recording

Want to select record the program on the Timer Fig.3 press the **GREEN** button.

Clear timer Menu/Timer/Recording

Select the program you want to delete from the Timer Fig.2 and press the **BLUE** button and **RED** button.

You will see a message if you want to do this, press the **OK** button and the timer is cleared Fig.4





LED

Open the main menu, use the arrow keys ▲ ▼ to Setup / System / Front Panel / LED and press the OK button.

You can define LED settings to your liking.

For this you use the arrow keys ▲ ▼ <> the **OK** button to confirm the save. Fig.1



Information

Open the main menu, use the arrow keys ▲ ▼ to / Information and press the OK button. You have information About (GigaBlue SW and HW) Network Service



Information About

About. There will be information on the firmware, HDD and Tuner is displayed Select channel. There you information of the current channel will be displayed.



Network

Select **Network**. There will be information on the Network, Network information is displayed



Select **Service:** There will be Information on the channels

RED Button Channel Info's GEEN Button PIDs YELLOW Button Transponder BLUE Button Tuner-Status

Channel



Software Update GigaBlue Box

Please back up software settings.

Before making software update please backup your settings

Backup system Settings

To back up settings, you need USB flash drive or USB HDD if you have a USB flash drive or USB HDD connected to GigaBlue. Go to the Menu **Setup /System / Software Management / Backup system Settings** and press the **OK** button. Fig. 1



Restore settings Software After the Software update to restore stored settings.

Go to the menu Setup/ System / Software Management /Restore settings and press the OK button. Fig. 2





Backup Image

To Backup Image, you need USB flash or USB HDD if you have a USB flash or USB HDD connected to GigaBlue.

Go to the Menu Setup /System / Software Management / Backup Image and press the OK button. Fig. 3



Software Restore

After the Software update to restore stored settings. Go to the menu Setup/ System / Software Management / Software Restore and press the OK button. Fig. 2

Software Update

Software Update via Internet

Go to in Menu / Setup

Software update and press the OK button. Fig. 1

GIGASLUS	3:04	Setup		<mark>/</mark> 16° <	\$ 23 °C 12 °C	Ğ
			Video Audio			
			Parental control CAM/CI System Software update			

Fig.1

Now go to Software update and press OK button. Fig. 2





Software Update GigaBlue Box

Software Update via Internet

It is now looking for the latest software. Fig. 3





After successful search, you press the OK button. The latest software is now installed on your GigaBlue box. Fig.4

GIGASLUS	3:10	Software up	odate	/ 16° 🖒	23 °C 12 °C Č
			enigma2-plugin-extensions-zaphistorybrowser Downloading		

Software Update GigaBlue

Software Update via Internet

After completion of the update, you will be asked whether the GigaBlue box to restart. Confirm with the OK button. Fig.5.



Fig.5

If you look like in Fig.6 message shown currently no update is on the server.



Update GigaBlue Box

Install Firmware

Perform firmware update at the GigaBlue box, please go to the site <u>http://gigablue-support.com</u>. There is described in each step. As an update is performed, this forum is always up to date. To make a software update via the Internet, follow the steps described on pages 68 and 69. Or visit the page <u>http://www.gigablue.de</u> support & Selling /Download service where you can also, if you register, add your own experience.

Installing Extensions

Please go to Menu / Extension and press the **GREEN Button.** Fig.1. The plugin information is loaded.

Scroll down to the next screen folder and open the folder with the OK button. Select the extension and now start downloading the OK button and confirm the next window with Yes Fig.3. The download will start. After a reboot, click the Browser under the Menu **extensions**.

You can install extensions prepared by us under extensions

You can install Picons prepared by us under Picons

You can install Channel-list prepared by us under Settings

You can install Skins prepared by us under Skins

You can install Systemplugin prepared by us under Systemplugins

Gig∧∃lue 0:49 ⊢	lerunterladbare Plugins	
	extensions extensions picons settings skins systemplugins picons	
		OK EXIT

PiP GigaBlue Box

PiP Picture in Picture

You can enable PiP when pressing 2x **BLUE** button.

PiP Picture in Picture

If you press 1x BLUE button. Fig.1

The following options are available RED Button: Put focus on the main screen

GREEN Button: Move Picture in Picture **YELLOW** Button: exchange channels **BLUE** Button: Picture in Picture disable

- Put focus on the main screen
 When PiP is activated, you can enable zap with the RED button.
 For the main Window. You can switch program in the channel list
- Move Picture in Picture
 You can use the GREEN button to
 move the PIP window and resize.
 You can PiP window move with
 the arrow keys ◀▶ ▼ ▲ on the
 remote control. The size of the
 window can be changed with the
 channel button ▲ ▼.



Fig.1



Fig.2

- Exchange Channels
 You can use the <u>YELLOW</u> button When PiP is activated, you can PiP swap main channel
- **Picture in Picture disable** F.1. You can use the **BLUE** Button: Picture in Picture disable
Update GigaBlue Box

Extensions

Open the main menu, use the arrow keys ▲ ▼ to **extensions** and confirm with the **OK** button or 1x **GREEN** Button



Installing Extensions

Please go to Menu / Plugin and press the **GREEN Button.** Fig.1. The plugin information is loaded.

Scroll down to the next screen folder and open the folder with the OK button.

Select the extension and now start downloading the OK button and confirm the next window with Yes Fig.3. The download will start. After a reboot, click the Browser under the Menu **extensions**.

You can install extensions prepared by us under extensions

You can install **Picons** prepared by us under **Picons**

You can install Channel-list prepared by us under Settings

You can install Skins prepared by us under Skins

You can install Systemplugin prepared by us under Systemplugins



Update GigaBlue Box

User Interface / Basic Settings

Go to the menu and use the arrow keys ▲ ▼ ◀► Setup / System / User interface / basic settings and confirm with OK

Use the arrow keys $\blacktriangle \lor \blacklozenge \lor$ to change the information on the channel list, EPG, skin, etc.

Press OK to save.



Button allocation

Go to the menu and use the arrow keys ▲ ▼ ◀► Setup / System / User Interface / Hot Key and confirm with OK

The key allocation feature allows you to customize the buttons on your remote control to your wishes. Here is an example using the web browser.

Please use the Button of which is to be occupied, in our case F4 Abb2 and confirm by pressing the **OK** button. This will open as shown in the displayed menu. By pressing the blue button (Add) opens.

There you have the option of either a function of GigaBlue box or a plugin inflict added.



Operation of GigaBlue Box

User Interface / Skin

Skin

Go to the menu and use the arrow keys ▲ ▼ ◀► Setup / System / User Interface / Skin and confirm with OK

Use the arrow keys $\blacktriangle \lor \blacklozenge \lor$ to select Skin and accept with **OK**



Weather

Open the main menu, use the arrow keys ▲ ▼ to Setup / System / User Interface / WeatherGigaBlue Pax and press the OK button.

Navigate the menu using the arrow keys $\blacktriangle \lor \blacklozenge \lor$ enter the Weather ID and press the **OK** button to save. Abb1.

You can find weather ID number under the site <u>http://metrixweather.open-</u> store.net/gigablue

Please enter your zip code or city name and press Search, you will see weather ID.



Position and Size

left 1 width 1 top 1 height 1 beight 2 OK Scancel

Go to the menu and use the arrow keys ▲ ▼ ◀► Setup / System / userinterface / location and size with OK

Use the arrow keys $\blacktriangle \lor \blacklozenge \lor$, you can adjust margins and select accept with OK

Web browser GigaBlue Box

Install Web browser

Please go to the Menu **Extensions** and press the **GREEN** button. Fig.1 The plugin information is loaded. Scroll down to the next screen, **extensions** and open the folder with the **OK** button. Now go down to Chromium Fig. 2 Start the download with the OK button and confirm the next window with Yes. Fig.3. The download will start. Please wait until installation is finished. After installing please GigaBlue Box start new. You can find the browser Under the Plugin Browser

Fig.3. Chromium Webbrowser





Fig.3

Web browser navigate

Please connect via the USB port, a cordless keyboard and mouse or GB RCU with the keyboard. You can use the Web browser to the **GigaBlue Remote Control**. Please press **Yellow** button Fig.3



Web interface

Web interface

Web-IF, the web interface of GigaBLueBox is a part of the image. Get the latest and the expert versions of WebIf there by CVS. You can access the Web user interface of GigaBlueBox via the WLAN / LAN connection. Serve with a browser. Via the Web Interface current states of the box are displayed (current station, EPG etc.) and it can control commands are passed on to the box.

Now open your Internet browser and type in the address bar the IP address of the box and confirm with the Enter key example 192.168.xxx.xxx and it will start the Web Interface, 192.168.xxx.xxx:8080 starts OpenWebinterface.

Here you can find all kinds of features to Live TV watch, schedule recordings, check the box and much more

A 192 168 160.67						C Q Suchen		GB v	/ebinterface	× 🔛	Open Webi		
	. Impressum - Impex-sat 🌇 http://store.impex-s	at () HD+ Emp	pfang – MyAz 🚦	Google								_	
OpenWe	bif					Q	lelloffe	nes Webin	terface f Gi	ür Lini gaBluc	ux-Rec e Quad	eiver Plus	
24 01:00 - 01:00 Cun Applicable	rent												
uptmenü ^		Aktuell	Favoriten	Anbieter	Satelliten	Alle Sender	EPG						1
D	▶ 📮19,2°DEUTSCHE												
Multi-EPG	→ 📮19,2°DEUTSCHE HD												
itstärke ^	→ 📮19,2°SKY												
	→ 📮19,2°SKY HD												
(()))	• 📮19,2°SKY SPORT												
	• 📮19,2°ORF												
schaltmenü	• 📮19,2°FRANKREICH												
chirmfoto	→ 📮19,2°HOLLAND												
er	• 📮19,2°SPANIEN												
nbedienung ^	→ 📮19,2°ENGLISCH												
1 2 3	+ 📮19,2°beIN SPORT												
4 5 6	→ 📮19,2°MTV												
7 8 9 MENIL O EXIT	• 📮19,2°DIVERSE												
	• 📮13°SKY ITALIEN												
ок о	• 📮13°TIVUSAT												
schalttaste+Klick für langen Tastendruck)	→ 📮13°ENGLISCH												
Bildschirmfoto	→ 📮13°POLEN												

GigaBlue Player for Mobile devices

You can also Gigablue Player app for mobile devices free download and install, for android, iOS from Google Player and from ITunes Store

You can operate your GigaBlue box with the app, as well as TV shows, schedule recordings, check the box and much more



Problem-solving

Debugging



Technical Specifications

Technical Specifications

General Information:

System	GigaBlue UHD Quad 4K
CPU	Hisilicon 1,6 GHz 4 x Core
RAM	1GB DDR4
FLASH	8GB MMC FLASH
Kernel	4.4.35
Front	
IR Receiver	1 x IR
Button	8 x Button
Indecater LED	2 x LED
Front Display	4 Digit / 7 Segment Display
USB 2.0	1 x USB Host
CI-Modul	
SmardCard	2 x S/C Slot
Rear	
Tuner 1	1 x DVB-S2X Tuner
DVB -S2 OUT	
Tuner 2	DVB-C/T2/
Wlan	Optional
Bluetooth	Optional
SD CARD	1x SD Card Slot
НОМІ	1 x HDMI Output
E-SATA	
USB 2.0 / 3.0	1 x USB Host / 1 x USB Host
S/PDIF	1 x Optical
RS-232	1 x RS-232
Ethernet	1 x RJ45:1000Mbps (1 x Gbit)
Power Switch	1 x I/O Switch
DC Input Jack	1 x Jack
Power	
E-PSU	12V/2A

Technical Specifications

Technical Specifications

Supplementary Infos:

Output Digital: Output level 0,5 V an 75 Ohm Abtastfrequenz 32 kHz, 44.1 kHz, 48 kHz SPDIF Output optisch

Output Video: Output level FBAS 1 V +/- 0.3 dB an 75 Ohm

Video-Parameter: Input level FBAS 1 V +/- 0.3 dB an 75 Ohm Teletext filtering corresponding ETS 300 472 Standard

TV-Scart: Output: FBAS, RGB selectable via OSD

Ethernet: 10/100/1000 Mbit compatible Network interface, WLan possible via USB

USB: 3 x USB port, (2 rear / 1 front) 1 x USB 2.0, (rear) 1 x USB 3.0 Anschluss, (rear) 1 x USB 2.0 Anschluss, (front)

LNB power supply to the Tuner: LNB Current 500mA max. ; Short Circuit protection LNB Voltage vertical < 14V no load, > 11,5V at 400mA LNB Voltage horizontal < 20V no load, > 17,3V at 400mA LNB Shut off Standby-Mode

Number of active Satellite positions: DiSEqC TM 1.0/1.1/1.2 und USALS (Rotor-Control)

External Power supply input voltage: Input: 110-240V AC / 50-60Hz / 0,6A Output: 12V / 2A

Power consumption: Normal: 15W (STB PIP: 10.5W, LNB: 4.5W) –if 1 DVB S Tuner used Standby mode: 9.3W Deep Stand-by Mode: 0.5W

General:

Ambient temperature +15°C...+35°C Humidity < 80% Dimension (W x D x H): 300 mm x 240 mm x 63 mm

Technical Specification

Technical Specifications

Features of GigaBlue Box 4K:

- Simple EPG (Electronic Program Guide): sortable by date or alphabetically
- Automatic search for additional air dates of a show and easy recording them as a timer
- Multi EPG graphed
- PiP Picture in Picture
- Timeshift (when connecting to HDD)
- · Record list by alphabet or date and free choice of different views
- Timer programming manually or by EPG
- Individually configurable timers, for example, single, repetitive or switch
- DiSEqC 1.0 / 1.1 / 1.2, Unicable and USALS
- Power Switch
- · Commissioning by the Startup Wizard
- Standard channel list for DVB-S/S2x and DVB-C / T2
- TV and radio channels via antenna and digital cable
- DVB-C HDTV and DVB-T2 compatible
- Teletext
- Teletext subtitles
- Radio Text
- protection of minors
- Sleep Timer
- Expandable based functions via plugins
- Using the web interface be passed on streams of which is connected via network with the
- GigaBlue Box TV / radio stations to any PC
- Web Browser
- UFScontrol Plugin for iPhone and Android smartphones
- IP TV, IP Radio
- The OSD supports different skins and languages

Universal Remote Control

UHD4K Universal RCU V2

1. Modus Auswahl

 STB (Gigablue) mode: Press [GIGA] button for the gigablue boxes
Mode Selection Universal Function: Press Device Selection [TV] / [AUX] / [DVD] button for other devices

2. Setting - manual search

- a) Switch on the device that you want to use with your universal Gigablue remote control.
- b) Find the CODE of your device from a code list (eg Lifetec 0050).
- c) Press and hold a device button (eg TV) [TV] / [AUX] / [DVD] on your Gigablue remote control for 3 seconds.
- d) Enter the four-digit code of your device within 10 seconds (eg 0050 Lifetec). If no entry is made within 10 seconds, the input function closes.
- e) LED goes out if the code has been accepted. If the LED flashes twice, the entered code was incorrect, please make sure you have the correct code and follow the steps again.
- f) Check the functions of the remote control. If some functions are missing, try an alternative code from the list. Repeat steps 3 to 6 until all basic functions are correctly implemented

3. Automatic adjustment of the universal function

If you have not succeeded in entering the code, or your brand is not listed in the list, you can use the automatic search function of codes.

a) Switch on the device you want to program.

b) Point the remote control at your device. Press a device key (eg TV) for 3 seconds, LED lights up, press for another 2 seconds without interruption and the LED light starts to flash. Now the automatic search has started, you can let go of the key.

c) The "Volume +" signal is transmitted automatically from the remote control. As soon as the volume of your device (eg TV) changes, immediately press the device button (eg TV) to stop the automatic search.

d) If you want to set devices such as CD player, tuner or AUX, a switch-off signal is transmitted to the terminal. As soon as the terminal turns itself off, press the device key on the Gigablue remote control to end the search.

Press the Power button for the device to turn on again and check the functions of the other buttons. e) Check the functions of the other buttons. If the other keys do not perform any function or function correctly, restart the search (see steps 2 to 4) to find a suitable code. Once the majority of the buttons are working correctly, the setting has been successful. Press the device key again (eg TV) to save it.

4. Manual setting

If you have not been successful with the manufacturer's code entry, you can also do a manual search to find the correct code

1. Turn on the device you want to program.

2. Point the remote control at your device. Press a device button (eg TV) for 3 seconds, the LED lights up, press for another 2 seconds without interruption and the LED light starts to flash. Now the automatic search has started, you can let go of the key.

3. Press the "Volume + button" every 1.5 seconds

4. As soon as the volume of your device changes or the device turns off, check the other buttons and their functions. If the majority of buttons do not work correctly, press "volume +" every 1.5 seconds to generate a new code and send it to the device. Once the majority of the buttons are working correctly, the setting has been successful. Press the device key again (eg TV) to save it.



Universal Remote Control

5. Read code

a) Press and hold the device key (eg TV) and the OPTION key, the indicator lights up immediately

b) Release the button and then press the number button 1 or 2 or 3 or 4 of the code display

c) LED flashes to indicate the number of current digital position: Press "1" to display the first code group number, press "2" to display the second code group number. Press "3" to display a third code group number "4" shows the fourth code group number.

Example: If the current code is set to 0016, the LED "1" will not flash. The LED "2" does not flash. Press "3" LED lights 1; The LED "4" flashes 6 times.

d) Press another key to exit the code recognition mode.

e) No button is pressed within 30s, light goes off automatically;

Example for code 0169

- a. Press TV and 1 the LED flashes 0 times.
- b. Press TV and 2 the LED will flash 1 time.
- c. Press TV and 3 the LED flashes 6 times.
- d. Press TV and 4 the LED will flash 9 times.

6. Check battery condition

When the voltage is lower than 2.4V, low power state,

When the LED is flashing green battery condition is OK

If the LED top left red flashes three times and slowly, battery condition is too weak. Please change the battery

7. Reset function

Press the device key (eg TV) and key 0 at the same time, as soon as the LED flashes three times, the settings are deleted and the remote control returns to the factory settings.

8. Change the system Code the remote control

You can change the system code of your GigaBlue remote, according to the GigaBlue model you want to use. System Code Mode 1 is set as default. Mode 2 is there to support these 2 frequencies to avoid overlapping with other remotes.

Mode 1: UE Plus, Ultra UE, Quad, Quad Plus, X1, X2, X3, Quad 4K, UE 4K, UE 4K c, X3 4K, Trio 4K, IP4K Mode 2: UE Plus, Ultra UE, Quad, Quad Plus, X1, X2, X3, Quad 4K, UE 4K, UE 4K c, X3 4K, Trio 4K, IP4K Fashion 3 & 4: reserved for future models.

1. Menu / Settings / System / Devices / Coding remote control

2. Select the code you want to have, code 1 or code 2 and save with OK

3. Press OK to go to the next menu. Press the GIGA and 5 buttons for approx. 5 seconds until the 3 x LED lights up.

4. Press the OK button

5. Code successfully saved.

This will only work if you have GigaBlue V2 remote from 2017

Would you like to use universal function, see code list. Please download under <u>http://www.gigablue.de</u>

GigaBlue universal Remote Control manual English down

WARRANTY CARD

In case of warranty, please contact the specified customer service. Should a problem with your GigaBlue HD Quad Plus occur.

Please download under <u>http://www.gigablue.de</u> the service request form down and fill it out completely. Please send the service request form and the original purchase receipt with the defective device.

Dealer.

Name: Street: Zip /City: Phone: Fax: Date: Signature:			
Stempel:			
Kaufdatum:		(inkl. Kaufbeleg)	
Impex-sat GmbH Beim Giesshaus 25348 Glückstad Tel.: +49 (0) 412 Fax: +49 (0) 412 E-Mail: service@ Gerät/ Artikelbez Seien-Nummer: Customer: Name: Street: Zip /City: Phone: Fax: Date: Signature:	Service + & Co. KG ; 7 dt 24 937262 24 937266 9 gigablue.de zeichnung:	eadresse:	





www.gigablue.de

Mistakes and changes are reserved.